NP-F970 Battery User Manual



Overview

The ZILR NP Battery has advanced technology to power your camera or external devices. Never miss a shot again due to low capacity batteries or waiting around for your next charge.

What's in the box

NP-F970 USB-C PD Battery

Product Code

ZRNPB01


Getting Started



Charging the NP-F970 Battery

The NP-F970 battery should be charged using the recommended ZILR USB-C PD Wall Charger (ZRACC01*) and USB-C cable (ZRUCC01*). This will ensure that the battery is charged correctly and supports fast charging via this method.

When using the Wall Charger (ZRACC01*), use the AC international adaptor plug for wall charger that matches your region.



Recommended charging setup




Do not overcharge. Do not expose the batteries and charger to fire or liquids.


LED Charging Indicators



NP-F970 Battery LED Charging Functions

The NP-F970 battery features LEDs to indicate the current charge level.







LED Power Indicators



NP-F970 Battery LED Power Usage Functions

The NP-F970 battery features LEDs to indicate the current power level while in use. Press the Output / Check Level button to view the current level.






Using the NP-F970 on devices



NP-F970 Battery on L-Series Devices

The NP-F970 battery can be used on L-Series devices using the standard 7.4V base terminal.




Using the NP-F970 with two devices



NP-F970 Battery USB-C Output

The USB-C output on the NP-F970 battery can be used to power another device while in use. First connect the battery to the compatible NP battery/L-Series device via the device's slot. Next plug in the USB-C to USB-C cable (ZRUCC01*) or the USB-C to Lightning cable (ZRUCL01*) to a USB-C or Lightning port on the second device. Press the Output Power button on the top of the NP-F970 battery. The second device will then be powered from the battery.

NOTE: Using two devices at one will drain the battery faster.




Using the NP-F970 as a power bank



NP-F970 Battery power bank mode

The NP-F970 also doubles as a power bank, enabling charing of mobiles and tablets. The battery does not require to be connected to a L-Series device for this to work. Simply plug in the USB-C to USB-C cable (ZRUCC01*) or the USB-C to Lightning cable (ZRUCL01*) to a USB-C or Lightning port on the mobile or tablet. Press the Output Power button on the top of the NP-F970 battery. The device will then be powered from the battery. The device will then charge. It also supports fast charging on devices that support this feature.



Support



Supported Accessories

- ZRACC01 USB-C AC Wall Charger
- ZRUCC01 USB-C to USB-C cable
- ZRUCL01 USB-C or Lightning cable
- ZRUCDB01 USB-C to Sony NP-FZ100

- ZRUCDB02 USB-C to Panasonic DMW-DCC16
- ZRUCDB03 USB-C to Nikon EN-EL15
- ZRUCDB04 USB-C to Canon LP-E6

Warning



Only use ZILR accessories with this product as accessories from other manufactures have not been tested and may cause damage to your device.



Do not over charge batteries.



Do not use this product near water or get it wet as it could cause risk to you or the device.



Do not expose batteries to heat or fire.



Do not overload the power on this device.

Looking for further help?

Please contact us should you require help or require more information. Contact us below:

https://www.zilr.pro/support/